



### AIR-HOSE COMPONENTS



CS6

CONNECTOR (STRAIGHT) 6MM

**CS6**  
**6MM**



CS8

CONNECTOR (STRAIGHT) 8MM

**CS8**  
**8MM**



CS10

CONNECTOR (STRAIGHT) 10MM

**CS10**  
**10MM**



CS12

CONNECTOR (STRAIGHT) 12MM

**CS12**  
**12MM**



CS15

CONNECTOR (STRAIGHT) 15MM

**CS15**  
**15MM**



### AIR HOSE CONNECTORS



CT6

CONNECTOR ('T'PCE) 6MM

**CT6**  
**6MM**



CT8

CONNECTOR ('T'PCE) 8MM

**CT8**  
**8MM**



CT10

CONNECTOR ('T'PCE) 10MM

**CT10**  
**10MM**



CT12

CONNECTOR ('T'PCE) 12MM

**CT12**  
**12MM**



### AIR HOSE CONNECTORS

CONNECTOR (ELBOW) 6MM

**CE6  
6MM**



CE6

CONNECTOR (ELBOW) 8MM

**CE8  
8MM**



CE8

CONNECTOR (ELBOW) 10MM

**CE10  
10MM**



CE10

CONNECTOR (ELBOW) 12MM

**CE12  
12MM**



CE12